Quattro Inverter/Charger

3kVA - 15kVA

Lithium Ion battery compatible

www.victronenergy.com



Quattro 48/5000/70-100/100



Quattro 48/15000/200-100/100



Ekrano GX or Cerbo GX

Provides intuitive system control and monitoring and enables access to our free remote monitoring website: the VRM Online Portal.



VRM Portal

Our free remote monitoring website (VRM) will display all system data in a comprehensive graphical format. System settings can be changed remotely via the portal. Alarms can be received by e-mail or push notification.

Two AC inputs with integrated transfer switch

The Quattro can be connected to two independent AC sources, for example the public grid and a generator, or two generators. The Quattro will automatically connect to the active source.

Two AC Outputs

The main output has no-break functionality. The Quattro takes over the supply to the connected loads in the event of a grid failure or when shore/generator power is disconnected. This happens so fast (less than 20 milliseconds) that computers and other electronic equipment will continue to operate without disruption.

The second output is live only when AC is available on one of the inputs of the Quattro. Loads that should not discharge the battery, like a water heater for example, can be connected to this output.

Split phase option

A split phase AC source can be obtained by connecting our autotransformer (see data sheet on www.victronenergy.com) to a 'European' inverter programmed to supply 240 V / 60 Hz.

Three phase capability

Three units can be configured for three phase output. But that's not all: up to 4 sets of three 15 kVA units can be parallel connected to provide 144 kW / 180 kVA inverter power and 2400 A charging capacity.

PowerControl - Dealing with limited generator, shore side or grid power

The Quattro is a very powerful battery charger. It will therefore draw a lot of current from the generator or shore side supply (16 A per 5 kVA Quattro at 230 VAC). A current limit can be set on each AC input. The Quattro will then take account of other AC loads and use whatever is spare for charging, thus preventing the generator or mains supply from being overloaded.

PowerAssist - Boosting shore or generator power

This feature takes the principle of PowerControl to a further dimension allowing the Quattro to supplement the capacity of the alternative source. Where peak power is so often required only for a limited period, the Quattro will make sure that insufficient mains or generator power is immediately compensated for by power from the battery. When the load reduces, the spare power is used to recharge the battery.

Solar energy: AC power available even during a grid failure

The Quattro can be used in off grid as well as grid connected PV and other alternative energy systems. Loss of mains detection software is available.

System configuring

- In case of a stand-alone application, if settings have to be changed, this can be done in a matter of minutes with a DIP switch setting procedure.
- Parallel and three phase applications can be configured with VE.Bus Quick Configure and VE.Bus System Configurator software.
- Off grid, grid interactive and self-consumption applications, involving grid-tie inverters and/or MPPT Solar Chargers can be configured with Assistants (dedicated software for specific applications).

On-site Monitoring and control

Several options are available: Battery Monitor, Multi Control Panel, Color Control GX or other GX devices, smartphone or tablet (Bluetooth Smart), laptop or computer (USB or RS232).

Remote Monitoring and control

Color Control GX or other GX devices.

Data can be stored and displayed on our VRM (Victron Remote Management) website, free of charge.

Remote configuring

When connected to the Ethernet, systems with a Color Control GX or other GX device can be accessed and settings can be changed remotely.



VRM app

Monitor and manage your Victron Energy system from your smart phone and tablet. Available for both iOS and Android.



Quattro	12/3000/120-50/50 24/3000/70-50/50	12/5000/220-100/100 24/5000/120-100/100 48/5000/70-100/100	24/8000/200-100/100 48/8000/110-100/100	48/10000/140-100/100	48/15000/200-100/100		
Nominal Battery Voltage	12/3000: 12 V battery 24/3000: 24 V battery	12/5000: 12 V battery 24/5000: 24 V battery 48/5000: 48 V Battery	24/8000: 24 V battery 48/8000: 48 V battery	48 V battery			
PowerControl / PowerAssist		40/5000.40 V Buttery	Yes				
ntegrated Transfer switch			Yes				
AC inputs (2x)		Input voltage range: 1	87-250 VAC Input frequency:	60/60 Hz Cos Φ >0.8			
Maximum feed through current (A)	2x 50	2x100	2x100	2x100	2x100		
Cw	6 kA 30 mS 10 kA 30 ms						
nput voltage range (VDC)		INVERTER	9,5 – 17 V 19 – 33 V 38 – 66	V			
Dutput ⁽¹⁾	Output voltage: 230 VAC ± 2 % Frequency: 50 Hz ± 0.1 %						
Cont. output power at 25 °C (VA) (3)	3000	5000	8000	10000	15000		
Cont. output power at 25 °C (W)	2400	4000	6400	8000	12000		
Cont. output power at 40 °C (W)	2200	3700	5500	6500	10000		
Cont. output power at 65 °C (W)	1700	3000	3600	4500	7000		
Peak power (W)	6000	10000	16000	20000	25000		
nput current (A DC)	250 / 125	458/238/118	381/188	235	350		
Maximum continuous Output current (A~)	11	19	30	37	53/50		
Power factor range	±0.8	±0.8	±0.8	±0.8	±0.8		
Maximum output fault current	32 A peak 1 sec.	53 A 1 sec.	100 A 1 sec	100 A 1 sec	150 A 1 sec		
	93 / 94						
Maximum efficiency (%)	20/20	94 / 94 / 95	94 / 96 60 / 60	96 60	96 110		
Zero load power (W)		30 / 30 / 35					
Zero load power in AES mode (W)	15/15	20/25/30	40 / 40	40	75		
ero load power in Search mode (W)	8 / 10	10 / 10 / 15 CHARGER	15/15	15	20		
harge voltage 'absorption' (VDC)	14,4 / 28,8	14,4 / 28,8 / 57,6	28,8 / 57,6	57,6	57,6		
Charge voltage 'float' (VDC)	13,8 / 27,6	13,8 / 27,6 / 55,2	27,6 / 55,2	55,2	55,2		
Storage mode (VDC)	13,2 / 26,4	13,2 / 26,4 / 52,8	26,4 / 52,8	52,8	52,8		
Charge current house battery (A) (4)	120 / 70	220 / 120 / 70	200/110	140	200		
Charge current starter battery (A)	4 (12 V and 24 V models only)						
Battery temperature sensor	Yes						
Auxiliary output (A) ⁽⁵⁾	25	GENERAL 50	50	50	50		
Programmable relay ⁽⁶⁾	3x	3x	3x	3x	3x		
Protection ⁽²⁾	54	54	a-g	5.4	54		
/E.Bus communication port	or your section and the section of t						
General purpose com. port	2x	2x	2x	2x	2x		
Remote on-off	Yes						
Common Characteristics	Operating temp.: -20 to +60 °C Humidity (non-condensing): max. 95 %						
Maximum altitude	3500 m						
		ENCLOSURE					
Common Characteristics Battery-connection	Material & Colour: aluminium (blue RAL 5012) Protection category: IP20, pollution degree 2, OVC III Four M8 bolts (2 plus and 2 minus connections)						
230 VAC-connection	Screw terminals 13 mm ²	Bolts M6	Bolts M6	Bolts M6	Bolts M6		
	(6 AWG)	34/30/30	45/41	51	72		
Weight (kg)	19	470 x 350 x 280	45/41	51	12		
Dimensions (hxwxd in mm)	362 x 258 x 218	444 x 328 x 240 444 x 328 x 240	470 x 350 x 280	470 x 350 x 280	572 x 488 x 344		
		STANDARDS					
Safety Emission Immunity			C 60335-1, EN-IEC 60335-2-29, EN		00.6.2		
Emission, Immunity		EIN 55014-1, EIN 55014-2, EN-IEC 6		61000-6-1, IEC 61000-6-2, IEC 610	2-0-00		
Road vehicles			12 V and 24 V models: ECE R	10-4			
Anti-islanding		2) Non-linear loadt	See our website				
1) Can be adjusted to 60 HZ. 120 V models available on re 2) Protection key: a) output short circuit b) overload c) battery voltage too high d) battery voltage too low e) temperature too high f) 230 VAC on inverter output	tection key: utput short circuit verload attery voltage too high attery voltage too low mperature too high			 3) Non-linear load, crest factor 3:1 4) Up to 25 "C ambient 5) Switches off when no external AC source available 6) Programmable relay that can a.o. be set for general alarm, DC under voltage or genest start/stop function AC rating: 23 0 V / 4 A DC rating: 4 A up to 35 VDC, 1 A up to 60 VDC 			



Digital Multi Control Panel A convenient and low-cost solution for monitoring and control. With an on/off charger-only switch, full LED readout and a rotary knob to set PowerControl and PowerAssist levels.



VE.Bus Smart Dongle For monitoring and control via Bluetooth together with the VictronConnect app. It also measures battery voltage and temperature. Interface MK3-USB Needed to configure the MultiPlus, Can be used with the VictronConnect app or VE.Configure software. The interface connects to the MultiPlus via an RJ45 UTP cable and plugs into a USB port.



VictronConnect app

configure the MultiPlus

using your phone tablet

Use to monitor or

or PC.



Battery Monitor

To monitor battery state of charge via Bluetooth or the VRM portal. The BMV 712 Smart has display, while the SmartShunt does not have a display. Both communicate via Bluetooth and have a VE.Direct communication port.



